

Lustrous (Nonwoven)

Metallic finish. Conducts electricity — fabric smoothing tools only.

FIRE RATING

Class A

FSI 5 · SDI 30 · ASTM E84

CLEANABILITY

Washable

ASTM F793 Type II · Nonwoven

⚡ **Electrical & Signal Warning:** This wallcovering contains metallic particles and **can conduct electricity**. It must not contact or extend into electrical-outlet or light-switch boxes. **Turn off all electricity to the room before installation.** The metal layer may also interfere with Wi-Fi and radio reception.

Before you begin: Confirm all rolls share the same run/batch number, and cut rolls in sequence starting from the highest number. Inspect after hanging three strips — stop and contact Wall Snobs if any issue arises. **No labor claims will be honored. Material is accepted once more than three strips have been hung.**

WALL PREPARATION

A level 4 drywall finish is required. Walls must be clean, smooth, dry, undamaged and free of mold, mildew, grease or stains, with no more than 4% residual moisture — use a moisture meter. Prime with a universal white-pigmented, mold-inhibiting wallcovering primer. Mark only with a lead pencil; pen ink bleeds through. Keep the room above 65°F for at least 48 hours before hanging.

APPLICATION — PASTE THE SHEET

1. Measure the wall, allow for pattern match, **add 4"**, and cut. Work in sequence from the highest roll number down.
2. Apply a heavy-duty clay pre-mixed adhesive to the **back** of the strip with a pasting machine or paint roller. **Do not dilute.** Work it right out to the edges.
3. Fold each end to the middle, pasted sides together, edges aligned. **Do not crease.** Book for **10 minutes** so the adhesive can penetrate the backing.
4. **Line the pattern up at eye level**, letting any drift run off toward the ceiling and floor. Plumb the first drop with a level.
5. Smooth with **fabric smoothing tools only** — no plastic scraper — and do not burnish the face.
6. Seams may be set with a seam roller over plain paper, light pressure only; excess force marks the finish. A heat gun can help ease the material around corners.
7. **Double cutting:** overlap the second strip over the first, tape the seam underneath with low-tack tape, then double cut with a seam knife without cutting into the wall. Remove the waste and press flat. Leave no overlap — the surface will not adhere to itself. Keep seams at least 6" from corners.

⚠ **Critical:** Wash paste off the face as you go with a cellulose sponge rinsed in clean water, and blot dry with a clean cloth. **Do not rub, and never let adhesive dry on the surface** — it leaves a white residue. Do not apply a liquid topcoat to this finish.

CLEANING

Ordinary dirt: mild soap and warm water, working from the bottom of the wall upward, then rinsing top-down with clean water. Blot dry with a soft lint-free cloth. Never use steel wool, powdered abrasives or solvent-based cleaners — they strip the print and finish. Test any stronger cleaner on an inconspicuous area first.