

Matte (Nonwoven)

Our standard wallcovering. Paste the sheet, book 3–5 minutes.

FIRE RATING

Class A

FSI 5 · SDI 30 · ASTM E84

CLEANABILITY

Spongable

ASTM F793 Type I · Nonwoven

Before you begin: Allow wallcovering to acclimate on-site for 3 days. Confirm all rolls share the same run/batch number. Inspect after hanging three strips — stop and contact Wall Snobs if any issue arises. **No labor claims will be honored. Material is accepted once more than three strips have been hung.**

WALL PREPARATION

Walls must be clean, dry, and free from grease, dirt, mold, and loose material. Apply a stain-killing primer if necessary, then a primer designed for wallcovering installation. Allow to dry completely, then seal with wallpaper size. Allow to dry fully before proceeding.

APPLICATION — PASTE THE SHEET

1. Cut and hang one strip at a time. Cut to wall height plus 6". **Account for pattern match before cutting.**
2. Apply a lightweight pre-mixed clear adhesive to the back. Ensure paste reaches all edges.
3. Book the strip glue-on-glue — bring both ends to the middle. Rest 3–5 minutes.
4. Hang from the top and smooth with a soft brush. Keep paste off the face.
5. Low-tack painter's tape can protect the edge of previously hung strips from paste.
6. **Double cutting:** Overlap the second strip 1" over the first. Tape seam underneath with low-tack tape, double cut through both layers, remove waste, press seam flat.
7. Trim top and bottom with a sharp blade and straight edge. Change blades frequently.
8. Use a seam roller with plain paper — light pressure only; excess force may leave indentations.

⚠ Critical: Wash adhesive off the face immediately after hanging each strip — residue causes ink flaking. **Do not allow paste to dry on surface. Do not scrub.** Dry naturally with adequate ventilation. No added heat.

CLEANING

Clean with a damp, non-abrasive sponge or cloth. Do not scrub.